

Wasp DT10



© 2012 by Wasp Technologies. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from Wasp Technologies. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

The software is provided strictly on an “as is” basis. All software, including firmware, furnished to the user is on a licensed basis. Wasp Technologies grants to the user a non-transferable and nonexclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Wasp Technologies. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from Wasp Technologies. The user agrees to maintain Wasp Technologies’ copyright notice on the licensed programs delivered hereunder and to include the same on any authorized copies it makes, in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program delivered to the user or any portion thereof.

Wasp Technologies reserves the right to make changes to any software or product to improve reliability, function, or design. Wasp Technologies does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein. No license is granted, either expressly or by implication, estoppel, or otherwise under any Wasp Technologies, intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Wasp Technologies products.

Wasp Technologies is a registered trademark of Wasp Technologies. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Wasp Technologies

1400 10th St.

Plano TX 75074

<http://www.waspbarcode.com>

Table of Contents

| | |
|---|-----------|
| Chapter 1 - Getting Started | 1 |
| 1.1 Introducing the Wasp DT10 Mobile Computer | 1 |
| 1.2 Available Models | 2 |
| 1.3 Package Contents | 3 |
| 1.4 Battery Notices | 4 |
| 1.4.1 Battery Storage Notice | 4 |
| 1.4.2 Changing the Battery | 5 |
| 1.5 Cleaning the Mobile Computer | 7 |
| 1.6 General View | 8 |
| Chapter 2 – Getting Connected | 9 |
| 2.1 USB Connection | 9 |
| 2.2 Connection to USB Peripherals | 10 |
| 2.3 RS232 Connection | 11 |
| 2.4 WLAN Connection | 12 |
| 2.5 WPAN Connection | 13 |
| 2.6 Connection Cables | 14 |
| 2.7 Wireless and Radio Frequencies Warnings | 14 |
| Chapter 3 – Use and Functions | 16 |
| 3.1 Startup | 16 |
| 3.1.1 Using the Stylus | 17 |
| 3.1.1 Using the Joy Stick | 17 |
| 3.2 Data Capture | 18 |
| 3.2.1 Laser Data Capture | 18 |
| 3.2.2 Imager Data Capture | 19 |

| | |
|--|-----------|
| 3.3 Description of the Keys..... | 20 |
| 3.3.1 <i>Resetting the DT10</i> | 22 |
| 3.4 Status Indicators | 24 |
| 3.4.1 <i>LED Status</i> | 24 |
| 3.4.2 <i>Taskbar</i> | 24 |
| 3.5 Data Capture Configuration | 26 |
| 3.5.1 <i>Configure</i> | 26 |
| 3.5.2 <i>Capture</i> | 31 |
| 3.6 Control Panel..... | 32 |
| 3.6.1 <i>Buttons</i> | 32 |
| 3.6.2 <i>Registry</i> | 33 |
| 3.6.3 <i>Files Admin</i> | 33 |
| 3.6.4 <i>Wireless Communications</i> | 35 |
| 3.6.5 <i>Stylus Calibration</i> | 35 |
| 3.6.6 <i>Volume Settings</i> | 37 |
| 3.7 Windows Connection | 39 |
| 3.7.1 <i>Microsoft® ActiveSync®</i> | 39 |
| 3.7.2 <i>Bluetooth® Manager Device Setup</i> | 40 |
| 3.7.4 <i>FTP Server Settings</i> | 44 |
| 3.8 Backup Directory File Management..... | 45 |
| 3.9 Firmware Update | 45 |
| Chapter 4 –Technical Features | 46 |
| 4.1 Technical Data | 46 |
| 4.2 Reading Diagrams | 49 |

Chapter 5 – Test Codes 50

Safety Regulations 54

Glossary 71

Chapter 1 - Getting Started

1.1 Introducing the Wasp DT10 Mobile Computer

Thank you for purchasing the Wasp DT10 Mobile Computer. The DT10 mobile computer is designed to be compact and light weight without compromising durability.

The computer architecture of the DT10 starts with the industry leading XScale™ PXA310 microprocessor. 128 MB of RAM / 256 MB Flash is sized for running multiple, simultaneous applications, managing large databases or for running large applications when off-line autonomy is required. The memory storage capacity can be increased through the user accessible Micro SD Card Slot.

The DT10 can be paired with one of two operating systems. Microsoft Windows CE 5.0 with Microsoft WordPad and Internet Explorer 6.0 minimizes the operating system size for faster uploads and more storage space.

The DT10 provides voice and data wireless communication options to meet your business needs. A speaker and microphone equip the DT10 to handle VoIP phone calls or push-to-talk conversations. The Summit IEEE 802.11 abg radio's optimized transmit power and receiver sensitivity result in superior range with a tailored user interface for easy configuration and consistent management. Complimented by a CCX v4 security certification from Cisco, the DT10 provides infrastructure compatibility focused on enterprise requirements for encrypted communication and seamless roaming. Client side applications leverage internet protocol connections for hands-free voice picking and push to talk communications. Bluetooth® Wireless Technology connects headsets, printers and other peripherals while eliminating cumbersome wires and costly replacement of broken or damaged cables.

Two scanner options provide optimal flexibility for your application needs. A laser scanner tackles intensive applications where speed and a wide depth of field are essential. The 2D scan engine option leverages picture technology to capture a wide range of Linear, Stacked, and 2D codes while also providing the flexibility to capture a signatures or drivers license. Digital image decoding software reduces failed reads due to damaged and poor quality barcodes while enabling the user to scan from almost any orientation.

Durability ratings protect your computing investment against accidental drops and occasional exposure to liquids and dust. A touch color display provides an easy to read interface in a wide range of lighting conditions. The phone keyboard layout and four direction joystick increase associate efficiency. Push button battery lock provides an easy to locking mechanism for quick, no hassle battery exchanges.

Rechargeable Lithium polymer batteries in two sizes customize capacity. Charging cradles include a communication cradles for RS232 and USB. A powered vehicle dock and power adapter cable extend charging capabilities on the road.

1.2 Available Models

The brand new DT10 is available in different models depending on the options it is equipped with. All options are listed below:

- communication options: 802.11abg radio, Bluetooth®
- capture options: laser, imager
- compute options: Windows CE

For further details about the DT10 models refer to the web site: <http://www.waspbarcode.com>.

The currently available models are:

- DT10+Batch+1DGS+CE5, Batch, 128MB RAM/256MB Flash, 23-key Numeric, Std Laser with Green Spot, CE 5.0
- DT10+802.11+BT+1DGS+CE5, 802.11 abg CCX V4, Bluetooth, 128MB RAM/256MB Flash, 23-key Numeric, Std Laser with Green Spot, CE 5.0
- DT10+802.11+BT+2D+CE5, 802.11 abg CCX V4, Bluetooth, 128MB AM/256MB Flash, 23-key Numeric, Std 2D Imager, CE 5.0

1.3 Package Contents

The DT10 package contains:

- 1 DT10 mobile computer
- 1 AC/DC power supply
- 1 EU plug adapter
- 1 UK Plug Adapter
- 1 standard Mini USB cable
- 1 extensible stylus
- 1 user's manual on the disk
- 1 rechargeable standard battery pack + cover
- 1 hand-strap with stylus holder
- 1 Windows CE End User License Agreement (depending on models)

Any other packages will contain the accessories necessary for the DT10 connection to the host computer and to the network: the cradle, one or more connection cables.

Remove all the components from their packaging; check their integrity and congruity with the packing documents.

Keep in mind that rechargeable battery packs are not initially charged.

1.4 Battery Notices

Rechargeable backup batteries and battery packs are not initially charged. Therefore the initial operation to perform is to charge them. See below.

Do not use the DT10 until the batteries are charged for a minimum of 4 hours.

Annual replacement of rechargeable battery pack avoids possible risks or abnormalities and ensures maximum performance.

Charging the Batteries: The battery pack longevity varies according to many factors, such as the frequency of barcode scanning, RF usage, battery life, storage, environmental conditions, etc.

The battery icon on the Taskbar indicates when the battery pack is low.

There are three methods for charging the device:

- Recharge the battery pack by connecting the power supply directly to the DT10.
- Recharge the battery pack by using a Single Cradle or the DT10 Multi Battery Charger.
- Recharge by USB Direct connection with the host computer. This method entails longer charging times and is only possible if the mobile computer is turned off. Use only a USB-IF compliant USB port as a charging source.

During the charging process the LED positioned at the right side of the display is red constant. Once the charging process has been completed this LED is green constant.

If the battery pack is removed from the mobile computer, it can be recharged by inserting it into the rear slot of a Single Cradle or the DT10 Multi Battery Charger.

The battery level may not be displayed correctly for some minutes after the disconnection if the DT10 is disconnected from power supply before the charging cycle is completed.

The DT10 may feel warm during charging; this is normal and does not mean a malfunction.

1.4.1 Battery Storage Notice

Even if the storage temperature range is wider, In order to achieve the longest battery life, store the terminal and the spare batteries between 20 to 30 °C (68 to 86 °F).

CAUTION! The Batteries must be charged at a temperature ranging from 0° to +40 °C (+32° to +104 °F).

1.4.2 Changing the Battery

To correctly replace the battery pack, proceed as follows.

1. Turn off the DT10.
2. Press the latch release button and pull the battery latch down as indicated in the figure below:



3. Remove the cover and the battery pack. As the battery cover is lifted, the mobile computer automatically shuts off, in order to retain data during the pack substitution.



4. Install the new battery pack, first insert the bottom (contacts) side, then the upper side as indicated in the following figure:



5. Press the latch release button and pull the battery latch down to reinsert the cover.

Warnings: *Installing, charging and/or any other action should be done by authorized personnel and following this manual.*

The battery pack may get hot, explode, ignite, and/or cause serious injury if exposed to abusive conditions.

If the battery pack is replaced with an improper type, there is risk of explosion.

Do not place the battery pack in or near a fire or heat; do not place the battery pack in direct sunlight, or use or store the battery pack inside unventilated areas in hot weather; do not place the battery pack in microwave ovens, dryer, high pressure containers, on induction cookware or similar device. Doing so may cause the battery pack to generate heat, explode or ignite. Using the battery pack in this manner may also result in a loss of performance and a shortened life expectancy.

Use only an approved power supply. The use of an alternative power supply will void the product warranty, may cause product damage and may cause heat, explode or ignite.

The area in which the units are charged should be clear of debris and combustible materials or chemicals.

Do not use the battery pack of this terminal for power devices different from this mobile computer.

Immediately discontinue use of the battery pack if, while using, charging or storing the battery pack, the battery pack emits an unusual smell, feels hot, changes colour or shape, or appears abnormal in any other way.

Do not short-circuit the battery pack contacts connecting the positive terminal and negative terminal. This might happen, for example, when you carry a spare battery pack in your pocket or purse; accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the contacts of the battery pack (these look like metal strips on the battery pack). Short-circuiting the terminals may damage the battery pack or the connecting object. Do not apply voltages to the battery pack contacts.

Do not pierce the battery pack with nails, strike it with a hammer, step on it or otherwise subject it to strong impacts or shocks.

Do not disassemble or modify (i.e. bend, crush or deform) the battery pack. The battery pack contains safety and protection devices, which, if damaged, may cause the battery pack to generate heat,

explode or ignite.

In case of leakage of liquid from the battery, avoid contact with liquid the skin or eyes. If the contact occurs, immediately wash the affected area with water and consult a doctor.

Do not solder directly onto the battery pack.

Do not expose the battery pack to liquids.

Avoid any knocks or excessive vibrations. If the device or the battery is dropped, especially on a hard surface, you should take it to the nearest Authorised Repair Centre for inspection before continuing to use it.

Do not replace the battery pack when the device is turned on.

Do not remove or damage the battery pack's label.

Do not use the battery pack if it is damaged in any part.

Battery pack usage by children should be supervised.

Collect and recycle waste batteries separately from the device in comply with European Directive 2006/66/EC, 2002/95/EC, 2002/96/EC and subsequent modifications, US and China regulatory and others laws and regulations about environment.

1.5 Cleaning the Mobile Computer

You can clean the DT10 periodically with a slightly dampened cloth.

1.6 General View



- | | |
|---------------------------------------|----------------------------------|
| A) QVGA 64K Color Display | G) Microphone |
| B) Good Read or User Programmable LED | H) Strap with Stylus Holder |
| C) Charging Status LED | I) Laser Safety Label |
| D) Speaker | J) Rear Speaker |
| E) Scan Key | K) ON/OFF Power Key |
| F) Keyboard | L) Product Label (under battery) |
| | M) Battery Cover |




- | | |
|---------------------------------------|---|
| N) Data Capture/Laser Output Window * | P) Communication/Charger Connector (through cradle) |
| O) DC Charger Connector | Q) Mini USB Communication Connector (through cable) |

**Remove the protective file cover before use.*

Chapter 2 – Getting Connected

2.1 USB Connection


You can use any standard mini USB cable to directly connect the DT10 to a host computer to transfer data through the USB interface.



- A) Host Computer C) DT10
B) Standard Mini USB cable

Note: Connection through the cable is compliant to 2.0 USB standard.

The Single Cradle can be connected to the Host by any standard mini USB cable to transfer data through the USB interface.



- A) Host Computer C) DT10
B) Standard Mini USB cable D) Power Supply


* In this case the power supply is only necessary for battery charging. Insert the power supply plug into the power jack on the base of the cradle and attach the power supply to an outlet.

Notes:

- Connection through the cable is compliant to 2.0 USB standard.
- The actual data transfer speed can be appreciably lower than the maximum theoretical speed.

2.2 Connection to USB Peripherals

You can use a standard A (4 pin female) to mini A (5 pin male) USB cable to connect the DT10 to a keyboard or a memory. For all these devices, maximum current withdrawal must be below 100mA.



A) Keyboard with USB interface

C) Standard A to Mini A USB cable

B) DT10



A) USB hard drive/external memory source

C) Standard A to Mini A USB cable

B) DT10

Notes:

- Connect the USB peripheral to the cable first, then the cable to the DT10.
- The DT10 works with most USB peripherals. We cannot guarantee compatibility with all devices available in the market place.
- Connection is compliant to 1.1 USB standard.
- The actual data transfer speed can be appreciably lower than the maximum theoretical speed.

2.3 RS232 Connection

You can use a cable to directly connect the DT10 to a host computer to transfer data through the RS232 interface.




A) Host computer

C) DT10

B) WIN-NET (HRS
ST40X-18S-CV)

The Single Cradle can be connected to the Host by any standard 9-pin serial null-modem cable for RS232 communications.

Once the Host has been turned on, insert the DT10 mobile computer into the cradle.



A) Host computer

C) Single Cradle

B) CAB-427 Null-Modem

D) Power Supply

In this case the power supply is only necessary for battery charging. Insert the power supply plug into the power jack on the base of the cradle and attach the power supply to a power outlet.

2.4 WLAN Connection


DT10 abg radio models can communicate with the host using the on-board radio frequency component and an Access Point connected to the host computer.

For models using the abg radio, you can find information about the applet for radio configuration:

<http://www.summitdatacom.com/SCU.htm>.

To launch this utility you can tap the specific icon if it's visible on the taskbar or:

On Windows CE devices, you can open Connections folder or Control Panel from desktop and select the 'Summit Client Utility' icon.




Notes:

- 802.11 abg radio module is on by default, in order to avoid wasting energy, you can switch it off using the Wireless Communications applet.
- Suspending the terminal powers off the 802.11 abg radio and drops the radio connection. When the terminal resumes, depending on the radio power mode and security protocol selected, it may take up to 30 seconds for the 802.11 abg radio driver to re-associate the radio to the network.
- Area coverage and radio performance may vary, due to environmental conditions, access points types or interference caused by other devices (microwave ovens, radio transmitters, etc.)

- In case of heavy usage the DT10 *could get warm*, this is normal and *does not mean a malfunction*.

2.5 WPAN Connection

DT10 mobile computer models with Bluetooth® can communicate with other Bluetooth® enabled devices, such as a printer, within a range of 10 m, using the onboard Bluetooth® module.



A) DT10


B) Bluetooth Printer

Notes:


- In order to avoid wasting energy, the Bluetooth® module is off by default. If you need to have Bluetooth® working, the module must be powered on using the Wireless Communications applet, and perform the Discovery procedure.
- Suspending the terminal powers off the Bluetooth® radio and drops the piconet (Bluetooth® connection). When the terminal resumes, it takes approximately 10 seconds for the Bluetooth® radio driver to re-initialize the radio.
- Area coverage and Bluetooth® radio performance may vary, due to environmental conditions or interference caused by other devices (microwave ovens, radio transmitters, etc.), etc.

2.6 Connection Cables

- **RS232 Direct Connection:**
94A051022 WIN-NET SERIAL CAB (HRS ST40x-18S-CV)



- **Power Supply Polarity:**



2.7 Wireless and Radio Frequencies Warnings

- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications or attachments could damage the product and may violate laws and regulations.
- Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals generated by the DT10.
- Persons with pacemakers or other medical devices to follow the same recommendations provided by Health Industry Manufacturers Associations for mobile phones.

Persons with pacemakers:

Should ALWAYS keep this device more than twenty five (25) cm from their pacemaker and/or any other medical device;

Should not carry this device in a breast pocket;

Should keep the device at the opposite side of the pacemaker and/or any other medical device;

Should turn this device OFF or move it immediately AWAY if there is any reason to suspect that interference is taking place.

Should ALWAYS read pacemaker or any other medical device guides or should consult the manufacturer of the medical device to determine if it is adequately shielded from external RF energy.

In case of doubt concerning the use of wireless devices with an implanted medical device, contact your doctor.

- Turn this device OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.
- RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.
- An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If vehicle's wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Turn off the device when in any area with a potentially explosive atmosphere. Observe restrictions and follow closely any laws, regulations, warnings and best practices on the use of radio equipment near fuel storage areas or distribution fuel areas, chemical plants or where some operation involves use of explosive materials.

Do not store or carry flammable liquids, explosive gases or materials with the device or its parts or accessories.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked or showed.

Sparks in such areas could cause an explosion or fire, resulting in injury or even death.

- To safely disable the radio modules (WiFi/BT) do not power off the mobile computer, but use the Wireless Communications applet.

Chapter 3 – Use and Functions

The use of the DT10 depends on the application software loaded. However there are several parameters that can be set and utilities that can be used to perform some basic functions such as data capture, communications, file management, etc.

3.1 Startup

The DT10 turns on when the battery pack or the external supply is inserted.

After the battery pack is installed, use the [ON/OFF] key to turn the mobile computer on and off.

As soon as the mobile computer is on, the Windows CE 5.0 desktop configuration will appear on the screen. Wait a few seconds before starting any activity so that the mobile computer completes its startup procedure.



Windows CE Desktop

Use the stylus or joystick as suggested to select icons and options.

The mobile computer goes into power-off (low power with display and keyboard backlight off), when it is no longer used for more than a programmable timeout, which is defined in the POWER applet of the Control Panel. In this mode it can be awakened (resuming operation) by the [ON/OFF] key.

Note: The mobile computer can also be awakened or turned off by the application program.

3.1.1 Using the Stylus

The stylus selects items and enters information. The stylus functions like a mouse.

| | |
|----------------------|---|
| Double Tap: | Touch the screen twice with the stylus to open items and select options. |
| Drag: | Hold the stylus on the screen and drag across the screen to select text and images. Drag in a list to select multiple items. |
| Tap-and-hold: | Tap and hold the stylus on an item to see a list of actions available for that item. On the pop-up menu that appears, tap the action you want to perform. |

To recalibrate the touch screen use the Stylus Applet.

Note: Use only original styluses supplied with the product itself. In harsh applications, use of screen protectors should be taken into consideration, in order to extend the touch screen operating life.

To prevent damage to the screen, do not use sharp devices or any device other than the provided stylus.

Do not apply not necessary high pressures on the screen.

For applications where an intensive use of the touch screen is foreseen, please consider that touch screen components are subject to progressive wear.

3.1.1 Using the Joy Stick

The joystick selects items and enters information. The joystick can work like the directional arrow keys of a PC keyboard or can function like a mouse and control the mouse pointer. It is possible to switch between the two functioning modes by pressing blue modifier + BKSP keys in sequence.

| | |
|-----------------------------------|--|
| Arrow Keys Mode (default): | Move in the four directions: move forwards, backwards, upwards or downwards within text fields, scroll through a Menu list or browse among folder files. Press down: selects the current function (like the Enter key). |
| Mouse Mode: | Move in the four directions: move the mouse pointer forwards, backwards, upwards or downwards. Press down: like the left click of the mouse. |

Note: During a phone call, you can set the speaker volume by moving the joystick up and down.


3.2 Data Capture

To capture data first of all select the barcode icon on the bottom-right side of the display and tap the 'Capture' menu item then proceed with the following directions.

3.2.1 Laser Data Capture

To scan barcodes, point the DT10 laser model onto the code from a distance within the reading range while pressing the SCAN key.

The lighted band emitted by the laser must completely intercept the barcode as shown in the figure below.



If the scan has taken place correctly:

- the Good Read LED gets constant Green for a configurable time;
- if enabled, the GoodReadSound emits an acoustic signal;
- if enabled, the GreenSpot projects a green spot onto the bar code image.


Note: Remove the protective film cover over the Laser Output Window before use.

3.2.2 Imager Data Capture

The DT10 Imager captures a picture of the entire bar code. The omni-directional scanning does not require that the operator orient the bar code to align with the scan pattern.

To read a 1D or 2D code, simply point the DT10 Imager model onto the code and press the SCAN Key.

The DT10 Imager uses an intelligent aiming system pattern, similar to those on cameras, indicating the field of view, which should be positioned over the code:




Aiming System


If the aiming system pattern is centered over the entire symbology as shown in the following figure, either wait for the timeout or release the Scan key to capture the image.

A red beam illuminates the code, which is captured and decoded. You will get a good read.

Linear barcode



2D Matrix symbol



Relative Size and Location of Aiming System Pattern

The field of view changes its size as you move the reader closer or farther away from the code. The field of view indicated by the aiming system pattern will be smaller when the DT10 Imager is closer to the code and larger when it is farther from the code.

Symbologies with smaller bars or elements (mil size) should be read closer to the unit. Symbologies with larger bars or elements (mil size) should be read farther from the unit.

If the scan has taken place correctly:


- the Good Read LED gets constant Green for a configurable time;
- if enabled, the GoodReadSound emits an acoustic signal.

3.3 Description of the Keys

The DT10 provides a 23-key alphanumeric keyboard + ON/OFF key + joystick. The following image shows this keyboard.



Main Keys Function

| KEY | FUNCTION |
|---|---------------------------------|
|  | It starts barcode data capture. |



The joystick lets you move forwards, backwards, upwards or downwards, scroll through a Menu list, browse among folder files or select functions if pressed down.

It can work in two functioning modes: Arrow Keys Mode and Mouse Mode. It's possible to switch between them by pressing blue modifier + BKSP keys in sequence.



Yellow modifier: when pressed before a standard key, it enables the character or function printed in yellow above the key.



Blue modifier: when pressed before a standard key, it enables the character or function printed in blue above the key.



It powers the DT10 ON or OFF. It is placed on the upper left side of the terminal.



The ALPHA key is used to alternate numeric and alphanumeric use of the 10 numeric keys.

Special Function Icons

ICON FUNCTION



After a yellow modifier key press, it opens the Start menu.



After a yellow modifier key press, it opens the file manager.



After a yellow modifier key press, it switches ON/OFF the display backlight.



After a blue modifier key press, it switches ON/OFF the keyboard backlight.



After a blue modifier key press, it locks and unlocks the keyboard.

3.3.1 Resetting the DT10

Windows CE

There are several reset methods for the DT10.

A warm boot terminates an unresponsive application and clears the working RAM, but preserves both the file system and the registry.

A cold boot forces all applications to close and clears working RAM and files not resident on the persistent flash memory. Registry is restored from persistent memory if available or returned to factory default.

A Clean Boot restores the DT10 to factory configuration: registry and file system return to factory default.

Warm Boot

A warm boot closes all applications, clears the working RAM, but preserves the file system and registry.

If an application "hangs" initiate a warm boot to terminate the application.

To perform a warm boot, press these keys simultaneously:



Cold Boot

A cold boot is a complete reset of the DT10 in which all applications are forcibly closed and RAM is completely cleared. Registry is restored from persistent memory if a saved copy is available and RAM file system completely erased. You will lose any applications and data (registry too) which are not stored in persistent flash memory.

A cold boot is necessary when the Windows CE operating system locks up and the warm boot command does not work.

To perform a cold boot, press these keys simultaneously:



Clean Boot

A clean boot is a cold boot that causes the device to be restored to factory configuration. The DT10 will reset to its factory configuration, clear the working RAM and initialize the file system. You will lose any applications and data stored in persistent flash memory. At the next startup the system will ask to recalibrate the touch screen.

To perform a clean boot, follow these steps:

1. Perform a Cold Boot (see Cold Boot).
2. Quickly release all the keys when the screen goes black.
3. Within 1 second press and hold down the Esc and 0 keys until the left orange led starts blinking.
4. Release the Esc and 0 keys.
5. Enter 1 to proceed with the Clean Boot sequence. Enter 0 to cancel the Clean Boot and proceed with a Cold Boot.

| | Warm Boot | Cold Boot | Clean Boot |
|-----------------------------------|-----------|------------------------------------|-----------------|
| REGISTRY | Preserved | Restored from flash (if available) | Factory default |
| Flash Disk (Backup Folder) | Preserved | Preserved | Clean disk |
| RAM File System | Preserved | Reinitialized (factory default) | Factory default |

Note: Before performing a reset, it is recommended to:

- execute a system backup to keep your more important files and applications persistent;
- save the registry to non-volatile memory to guarantee the persistence of the Windows configuration.

3.4 Status Indicators



3.4.1 LED Status








The DT10 provides two different LEDs signaling the mobile computer status.

| LED | STATUS | |
|---|----------------|---|
| Good Read and General Purpose (left side) | Green | It is constant for a configurable time to signal that a successful read has occurred. |
| | Green/Red | It is also available to the application program. |
| Charging Status (right side) | Green constant | It is constant once the charging process has been completed. |
| | Red constant | It is constant while charging. |
| | Off | <i>if the charging stops due to high temperature, failures etc.</i> |
| | Orange | <i>it is constant while in pre-charge status</i> |

3.4.2 Taskbar

The Taskbar provides information about the time, the battery level, the keyboard function, and the decoding status.

| ICONS | DESCRIPTION |
|---|---|
| Time and Battery Icons | |
| 10.50 | It displays the time. |
|  | In Windows CE, they are representative of five different icons indicating the battery level. The icon is partially green when the power left is >20% and partially red colored when the power left is <20%. |
|  | It indicates that the battery is charging (Windows CE). |

| Keyboard Status Icons | |
|---|---|
|  | It indicates that the blue FUNC key has been pressed and is going to affect the next key press. |
|  | It indicates that the yellow FUNC key has been pressed and is going to affect the next key press. |
|  | It indicates that the ALPHA key has enabled the selection of the characters printed in orange. |
|  | It indicates the NUMERIC key selection, the ALPHA key has not been pressed. |
|  | It indicates that the ALPHA key has enabled the selection of the characters printed in orange and the Capslock is active. |
|  | It indicates that the keyboard is locked. |
| Decoding Status Icons | |
|  | It indicates that the decoder is active (green), not active (grey). |



Windows CE Taskbar

3.5 Data Capture Configuration

From the Windows CE Taskbar, tap the "Decoding" icon to open a drop-down menu. Decoding can also be accessed from the Control Panel.

By selecting the *Info* item from this drop-down menu you can access information about the Scanner and the Software; the *Configure* item opens the configuration applet (Data Capture Configuration Window), while *Capture* accesses the data capture applet (Data Capture Window), which enables code reading.

The last menu item (*Wedge*) enables Wedge Emulation.



Windows CE


3.5.1 Configure

The Configuration applet contains the barcode scanning configuration parameters in a directory tree structure. The available barcode parameters are divided into two groups: Reader Parameters and Scan Parameters.

The Reader Parameters depend on the type of scanner module installed on the mobile computer and allow barcode configuration (i.e. enable/disable Code 39, check digit control, etc.).

The Scan Parameters are common to all scanner modules and allow control of the scanning device (i.e. beeper control, LED control, laser timeout, etc.).


Each Data Capture screen window corresponds to a branch of the tree, and the name of the current branch is displayed at the bottom of each screen window.



Data Capture Configuration Window

The screen format shows two columns where the left column indicates branches or parameters. Branches have three dots in the right column (...). You can navigate through the tree structure using the stylus or keyboard arrows directly on the item field or from the menu.

Parameters have their corresponding current values in the right column. You can edit parameter values using the stylus or keyboard arrows directly on the item field or from the menu. To change a value for example, select the line of the value to be changed, choose Edit from the Parameter Menu then choose a new value from the values listed in the box (see following figures).



Selecting Data Capture Setup Parameters

Alternatively using the stylus, you can tap once directly on the value on the right column; continue tapping until the desired value is reached.

To activate a new configuration select the File ->Save Menu to send the new configuration to the barcode decoding software and save the new configuration. This will save the configuration to non-volatile memory preventing loss at the next system reset.

Reader Parameters

The barcode reading parameters and values are dependent upon the type of scanner module mounted in your mobile computer. For a detailed list of parameters and of their configuration procedures, please refer to the SDK Help file on the CD.

Scan Parameters

The Scan Parameters are common to all scanner modules and allow control of the scanning device. The Scan parameters are described as follows:

ScanTimeout: the maximum time, in milliseconds, during which the scanner remains on without decoding any barcode.

BeepType: if set to dual tone, the good read beep is a sequence of high and low pitch sounds. If set to monotone, the beep is a single pitch sound.

BeepDuration: the time interval, in milliseconds, during which the beeper will sound when the scanner reads a code. To disable the beeper, set this value to 0.

BeepFrequency: determines the frequency in Hertz of the beeper.

GoodReadSound: is the beep sound emitted when the scanner reads a code.

LedDuration: the length of the good-read led pulse, in milliseconds.

LedPulses: the number of times the good-read led pulse is emitted when the scanner reads a code.

ContinuousMode: disables the effect of the ScanTimeout parameter.

KeyboardEmulation: if enabled all scanned data are transformed into keyboard events and can therefore be displayed and saved to a file as if input from the mobile computer keyboard.

SoftTrigger: when enabled, the laser can be turned on/off by the application software.

ScanAlwaysOn: enables the scanner for barcode reading independently from the application software.

GreenSpotDuration: determines the duration (measured in milliseconds) of the green spot feedback, which provides a “good read” green dot directly on the code, where the operator usually tends to be looking.

NotPrintableChar: if set to “Remove”, all not printable characters included in the scanned data are deleted and the final barcode will include only printable characters.

ScanButton: enables/disables the scan button. If the scan button is disabled, the reader can be triggered under software control

Default Settings

The following tables contain the default values for the major barcode setup parameters, according to the type of scan engine mounted on the mobile computer. For a complete list of parameters and of their configuration procedures, please refer to the SDK Help file on the CD.

| SCAN PARAMETERS | LASER MODELS | IMAGER MODELS |
|-------------------|--------------|-----------------|
| ScanTimeout | 5000 | Not available |
| BeepType | Dual tone | Not available |
| BeepDuration | 20 | Not available |
| BeepFrequency | 2000 | Not available |
| GoodReadSound | Beep | <i>Beep.wav</i> |
| LedDuration | 200 ms | 200 ms |
| LedPulses | 1 | 1 |
| ContinuousMode | Disabled | Disabled |
| KeyboardEmulation | Enabled | Enabled |
| SoftTrigger | Enabled | Enabled |
| ScanAlwaysOn | Disabled | Disabled |
| GreenSpotDuration | 1000 | Not available |
| NotPrintableChar | Leave | Leave |
| ScanButton | Enabled | Enabled |

| BARCODE SYMBOLOGY SPECIFIC READER PARAMETERS | LASER MODELS | IMAGER MODELS |
|--|-----------------|------------------|
| UPC A | Enabled | |
| UPC E | Enabled | |
| EAN 8 | Enabled | |
| EAN 13 | Enabled | |
| UPC/EAN/JAN | Not available | Enabled |
| Code 39 | Enabled | Enabled |
| Code 39 Full ASCII | Disabled | Disabled |
| Code 32 | Disabled | Not available |
| 2/5: Interleaved | Enabled | Enabled |
| 2/5: Industrial | Disabled | Not available |
| 2/5: Matrix | Disabled | Not available |
| Code 128 | Enabled | Enabled |
| EAN 128 | Enabled | Disabled |
| Codabar | Disabled | Enabled |

*In the Imager models these codes may only be enabled or disabled as a group by the UPC/EAN/JAN family selection.


| BARCODE SYMBOLOGY SPECIFIC READER PARAMETERS | LASER MODELS | IMAGER MODELS |
|--|-----------------|------------------|
| MSI | Disabled | Not available |
| Plessey | Disabled | Not available |
| Code 93 | Disabled | Enabled |
| Code 11 | Disabled | Not available |
| GS1 Databar | Disabled | Enabled |
| GS1 Databar Omnidirectional | Disabled | Not available |
| GS1 Databar General | Not available | Enabled |
| GS1 Databar Limited | Disabled | Enabled |
| GS1 Databar Expanded | Disabled | Enabled |
| PDF - 417 | Not available | Enabled |
| Data Matrix | Not available | Enabled |
| QR | Not available | Enabled |

| | | |
|---------------------------------|---------------|-----------|
| POSTNET | Not available | Disabled* |
| PLANET | Not available | |
| Japan Post | Not available | |
| Australia Post | Not available | |
| KIX Code | Not available | |
| Royal Mail Code (RM4SCC) | Not available | |

* These codes may be enabled individually but are disabled as a group.


3.5.2 Capture

The Data Capture applet (Capture) enables code reading.



Data Capture Window

Data Capture can also be enabled through the Configuration applet by selecting File ->Scanner from the main menu, or by enabling the parameter Scan Always On in the Scan Parameters branch.



Enabling the Data Capture

3.6 Control Panel

From the Windows CE Desktop, double tap on the "My Device" icon and then double tap on the "Control Panel" icon to open the Windows CE control panel main window. The Control Panel can also be launched from Start ->Settings ->Control Panel.

APPLET programs are displayed as icons; one icon corresponds to each APPLET.



Windows CE Control Panel

3.6.1 Buttons

To configure the way up/down and the rest of keys control repeats, use the Up/Down Control applet (Start -> Settings -> Personal -> Buttons -> Up/Down Control).



Windows CE Buttons Icon

You can also select to wake up the terminal by the SCAN key.

To assign desired applications to be launched by one of the keys, refer to DFU Reference Guide.

3.6.2 Registry


The REGISTRY ADMIN applet provides management of Windows CE 5.0 registry.

From the Windows CE control panel main window, select the REGISTRY ADMIN applet by double tapping the Registry Admin icon.

The Registry Administration Main window appears. Two functions are available:

- Save Registry allows permanently saving the Windows configuration (example: custom configuration of screen desktop background color, or network adapter configuration) to non-volatile memory (SAVE button).
- Restore Default Registry allows restoring the initial factory default configuration (Restore Default button). After restoring the factory default configuration, you must perform a warm boot.

Saving the registry to non-volatile memory guarantees the persistence of the




Registry Administration Window

3.6.3 Files Admin

The FILES ADMIN applet enables control of the permanence of files in the Windows CE System Folder.

Two functions are available on the Files Admin Main window by means of two buttons:



Files Admin Main Window

Save Session: with this button all files will be permanently saved in the \Windows directory in non-volatile memory. This function guarantees the steady maintenance of every file produced during the current working session - even of sub-directories and relevant files - with the exception of the files belonging to the FLASH image.


These current working session files will be backed-up in the \Backup\Windows directory.

At the next cold boot, the files previously saved in the \Backup\Windows directory will be restored to the Windows directory.

Safe Setup: with this button, the installation of software programs will be saved to non-volatile memory (Backup directory). Before doing this, it will be checked that the Backup directory has enough space to save the files. If the directory space is not enough, an error message will be shown and the program will exit the Safe Setup function.

Two activating procedures are available for Safe Setup:

- Select an installation file (for example, a .CAB cabinet file) from the Safe Setup mask.



Safe Setup First Mask

Then select \Windows or a relevant sub-directory in the path box. Then, Safe Setup will recognize the new files and directories present in the \Windows directory, and will copy them to the \Backup\Windows directory. At the next cold boot, these files will be restored.

- Simply skip the first mask either by closing it or by pressing the ESC key. When it closes, a new mask will pop up: it will enable any type of installation (even remote ones like ActiveSync® installations). Make sure the installation directory is \Windows or one of its sub-directories. After installation, tap OK: Safe Setup will save the new files in the \Backup\Windows directory.



Safe Setup Second Mask


3.6.4 Wireless Communications

The WIRELESS COMMUNICATIONS applet provides management of the 802.11 abg radio, the Bluetooth® modules.



Windows CE Wireless Communications Icon

If the mobile computer supports Windows CE, select the WIRELESS COMMUNICATIONS applet by double tapping the Wireless Communications icon. The following window will appear:



Wireless Communications Window

3.6.5 Stylus Calibration

You might need to recalibrate the touch screen (i.e. when you attempt to select one item with the stylus, another item is erroneously selected).

To recalibrate the touch screen on Windows CE, complete the following steps:

1. Select **Start > Settings > Control Panel > Stylus** to open the **Stylus Properties** dialog as shown in Figure 1.
2. Adjust **Double-Tap** sensitivity if needed or desired.
3. Select the **Calibration** tab to open the **Calibration** application.




Figure 1

4. Tap **Recalibrate** to open the **Calibration** screen shown in Figure 2.
5. Carefully press and briefly hold stylus on the center of the target. Repeat as the target moves around the screen. Press the **<ESC>** key to cancel the stylus calibration.
6. Press the **<ENTER>** key or tap the screen to accept the new calibration settings. Press the **<ESC>** key to keep the old settings.
7. New calibration settings are persistently saved in registry.

Startup stylus calibration on Windows CE

When starting the terminal, a stylus calibration screen comes up if valid calibration settings are not available. This happens in the following circumstances:

1. At the first startup of the terminal.
2. After restoring registry default settings using the applet **Registry Admin** and performing a warm boot.
3. After a **Clean Boot**.
4. After a **Firmware Update**.


3.6.6 Volume Settings

Windows CE

From the Windows CE control panel main window, select the Audio applet by double tapping the 'Audio' icon:




The Audio applet allows to set the recording volumes of the main microphone and of the headset microphone. Also, it allows to set the headset volume when the user is listening to an audio file.




Audio Window

From the Windows CE control panel main window, select the Volume & Sounds applet by double tapping the Volume & Sounds icon:



The Volume & Sounds applet allows you to manage the audio features of the rear speaker and appears as follows:



Volume & Sounds Window

3.7 Windows Connection

To connect the DT10 to another device (i.e. Host PC) from Windows, several programs are available. These programs require specific electrical connections in order to function properly.

3.7.1 Microsoft® ActiveSync®

Microsoft® ActiveSync® gives you the possibility to connect your desktop computer to your DT10 and synchronize the information on them. Synchronization compares the data on the DT10 with that on the desktop computer and updates both computers with the most recent information.

With ActiveSync®, it is possible to:

- Back up and restore DT10 data.
- Copy files between DT10 and desktop computer.
- Synchronize files by selecting a synchronization mode.

You can establish an ActiveSync® connection to your DT10 through the following electrical interfaces:

- **USB** either directly or through the Single Cradle
- **Bluetooth®**

It is possible to constantly synchronize while connected to a desktop computer or, alternatively, synchronization can be performed only when the synchronize command is chosen. You can select which information types are synchronized and control how much data is synchronized.

Note: By default, ActiveSync® does not automatically synchronize all types of information. Use ActiveSync® options to turn synchronization on and off for specific information types.

For example:

Synchronize Microsoft Word and Microsoft Excel files between the DT10 and the desktop computer. The files will automatically be converted to the correct format.

Notes:

- Visit the following Microsoft Web site for the latest in updates and technical information:
<http://www.microsoft.com/windowsmobile/activesync/default.mspx>.
- Microsoft® ActiveSync® Remote is no longer supported in Windows CE. For backward compatibility you can download it from the Internet. We suggest enabling the FTP Server and connecting to an FTP Client.

3.7.2 Bluetooth® Manager Device Setup

Windows CE Bluetooth® Manager Device Setup

Before turning on Bluetooth®, ensure that the two devices are within close range and that both Bluetooth-enabled devices are discoverable.

1. Open the Bluetooth® control panel by tapping Start > Settings > Connections tab > Bluetooth Manager.
2. Tap Settings. The Settings tab allows you to enable or disable the Bluetooth radio and specify settings for Incoming Connections.
3. Select or clear the “Enable Bluetooth Radio” check box:



Tap Find Me if you want to make the DT10 visible to other Bluetooth devices for 60 seconds, allowing them to set up a connection.



Note: By default, Bluetooth® is turned off. If you turn it on, and then turn off your device, Bluetooth® also turns off. When you turn on your device again, Bluetooth® turns on automatically.

To create a Bluetooth® partnership between your device and another device that has Bluetooth®

capabilities, ensure that the two devices are turned on, discoverable, and within close range.

1. Open the Bluetooth® control panel by tapping Start > Settings > Connections tab > Bluetooth Manager.
2. Search for the type of Device(s) you want to connect to by tapping Printer, Serial or All. The DT10 will search for Bluetooth® Devices within range.


Note: If you attempt to set up a connection when the Bluetooth® Radio is disabled, you will receive a message reminding you that the radio is turned off, and asking you if you want to turn it on. Tap Yes if you need to enable the Bluetooth® Radio.

3. Once searching is complete, Bluetooth® Device Profiles will be displayed in the Discovery tab. You can set up a connection to a device on the list, or clear it from the list by tapping the Clear button:



To set up a connection:

1. From the list of available devices, double tap the one you want to activate, or select and then tap Connect. The resulting dialog will display services that are available on the device:



2. Select the service you want to connect to. The following table lists different types of service.

| Service |
|---|
| DIALUP NETWORKING |
| Printer |
| File Transfer Protocol (FTP) Object Exchange (OBEX) |
| Object Push (OPP) Object Exchange (OBEX) |
| ActiveSync |
| Human Interface Device (HID) - Keyboard |
| Serial |

Virtual Port allows you to specify the incoming port, which is used to communicate serially with an incoming device just as if it were a physical COM port. This option is available only if you have selected a Printer or Serial service.

You can also select Encrypt or Authenticate from the Bluetooth® control panel to apply or modify those settings.

1. To require Authentication, tap the checkbox, then tap OK.
2. The Authentication Request dialog will then open, requesting that you enter a PIN. Use the Input Panel to type in the PIN.




3. Tap OK to complete.

The dialog will also appear when an Authentication request is received from another device.

Once you have set up a Pairing, you can view the settings by double-tapping its name from the Connections tab. The Pairing info dialog will display different options, depending on what type of device you have selected and what service you use.

- For a printer connection, tap the arrow to change the Virtual Port, or Delete to remove the device pairing.
- Tap Sync to initiate a Sync (available only if the service is an ActiveSync connection).



The icons displayed in the taskbar at the bottom of your DT10 screen will show you the state of the Bluetooth connection.

3.7.4 FTP Server Settings

The DT10 Windows CE Operating System includes a sample File Transfer Protocol (FTP) server. FTP is used for copying files to and from remote computer systems over a network using TCP/IP. You can establish a connection to your DT10 using its FTP Server through the following interfaces:

WLAN using the 802.11 abg radio

Proceed as follows:

1. Create a registry file (extension .reg) to setup and enable FTP Server communication. A simple example file for anonymous logon is given below:

```
REGEDIT4

[HKEY_LOCAL_MACHINE\Comm\FTPD]
"DefaultDir"="\\"
"AllowAnonymousUpload"=dword:00000001
"UseAuthentication"=dword:00000000
"BaseDir"="\\"
"IsEnabled"=dword:00000001
"LogSize"=dword:00001000
"DebugOutputMask"=dword:00000017
"DebugOutputChannels"=dword:00000002
"IdleTimeout"=dword:0000012c
"AllowAnonymous"=dword:00000001
"AllowAnonymousVroots"=dword:00000001
```

2. Copy this file to the DT10 using ActiveSync®.
3. Launch the .reg file from the DT10.
4. Perform a warm boot on the DT10.
5. From the PC > Explorer address bar (or running an FTP Client from the PC), enter the DT10 IP address.

Note: For more information on FTP Client/Server connections refer to the following web page:

<http://msdn2.microsoft.com/en-us/library/aa922316.aspx>.

3.8 Backup Directory File Management

All of the Windows CE 5.0 system files reside in RAM (volatile memory) except for the Backup directory, which resides in FLASH (non-volatile memory). Therefore the contents of the Backup directory are persistent even if the mobile computer is re-booted or the battery pack is changed.

You can save your more important files that you don't want to lose due to mobile computer re-boot, in the Backup directory or create a sub-directory within Backup.

Even though the Windows Directory resides in RAM, it often contains files or sub-directories created by the user or by installation programs that you don't want to lose at re-boot. To keep these files persistent it is necessary to copy them to the directory \Backup\Windows. This directory doesn't exist originally (only Backup exists), and therefore it must be created. At the next cold boot, before activating the shell, Windows CE 5.0 will copy the contents including all sub-directories of \Backup\Windows to \Windows.

Likewise, to maintain files that must be run at Windows CE 5.0 startup, (i.e. .exe, .lnk, .vb, .htm, etc.), it is necessary to copy them to the directory \Backup\Startup. This directory does not exist originally (only Backup exists), and therefore it must be created. The application programs will be run after any type of re-boot (both software and cold boot).

As an alternative to the Safe Setup function, it is possible to copy the .cab files to the directory \Backup\Cabfiles (the Cabfiles sub-directory doesn't exist originally and must therefore be created) and perform a mobile computer cold boot to have the application installed. Once these files are copied to the directory \Backup\Cabfiles, the application will be run after each re-boot.

From the second cold boot on, a message may be displayed such as "<application name> is already installed. Re-install?". This message blocks the boot process. Press the [Enter] key to continue the system initialization.

3.9 Firmware Update

The DT10 is equipped with a tool that implements a firmware update service. For further information, refer to DFU Reference Guide.

Chapter 4 –Technical Features

4.1 Technical Data

| PHYSICAL CHARACTERISTICS | |
|--------------------------------|---|
| DIMENSIONS (LXWXH) | 15.2 x 5.5 x 4.0 cm / 5.9 x 2.2 x 1.6 in |
| WEIGHT (DEPENDING ON MODEL) | 220 g / 7.76 oz (incl. 1100 mAH battery) 250 g / 8.81 oz (incl. 2000 mAH battery) |
| AUDIO | Rear Speaker for beeps and ringing tones Microphone and Front Speaker for phone calls Headset |
| LEDS | Two-color Good Read/Programmable Charging Status |
| DISPLAY | 64K Color TFT LCD with 320 x 240 pixel resolution (QVGA), with LED backlight and touch screen, antiglare and antiscratch protection |
| KEYBOARD | 23 Plastic Top - Backlit Keys + Joystick + lateral ON/OFF key |
| OPERATING TEMPERATURE* | 0° to +50 °C / 32 °F to +122 °F |
| STORAGE TEMPERATURE | -20° to +70 °C / -4° to +158 °F |
| HUMIDITY** | 10 to 80% non condensing for temperatures < 38 °C |
| DROP RESISTANCE*** | 1.2 M / 3.9 FT |
| ENVIROMENTAL SEALING | IP 54 |
| ESD PROTECTION | 4 KV contact discharge, 8 KV air discharge |

* Battery must be charged at a temperature ranging from 0° to +40 °C.

Close to the limits of the working temperature, some display and/or battery performance degradation may occur.

** Multiple rapid humidity and/or temperature variations may cause condensing.

*** Multiple drops can permanently damage the device.

| SYSTEM | |
|----------------------------|--|
| OPERATING SYSTEM | Windows CE 5.0 Professional |
| MICROPROCESSOR | Marvell XScale™ PXA 310 624 MHz |
| SYSTEM RAM MEMORY | 128 MB |
| SYSTEM FLASH MEMORY | 256 MB |
| POWER SUPPLY | |
| DC Supply | 5 V \pm 5% |
| Battery Pack | 1 cell Li-Pol or Li-Ion 1100 mAh@3.7 V (nominal) Alternatively 1 cell Li-Pol or Li-Ion 2000 mAh@3.7 V (nominal) |
| Internal Backup Battery | Rechargeable Ni-MH 30 mAh (2 x 15 mAh cells) |


| COMMUNICATIONS | | | | |
|--------------------------------|---|------------------|-----------------|--------------|
| INTERFACES | | | WIN CE COM PORT | |
| | Bluetooth® Interface | | COM5 | COM5 |
| | SERIAL INTERFA CE | RS232 USB 1.1 | COM1 COM6 | COM1 COM6 |
| LOCAL AREA NETWORK (LAN) | Summit IEEE 802.11 abg Frequency range: Country dependent, typically 2.4 and 5.2 GHz CCX v4 Security | | | |
| PERSONAL AREA NETWORK (PAN) | Bluetooth® IEEE 802.15, Class 2, Version 2.0 | | | |

| READING OPTIONS | |
|----------------------------------|---|
| LASER CHARACTERISTICS | |
| SCANNING RATE - BIDIRECTIONAL | 104 ± 12 scan/sec |
| MAXIMUM RESOLUTION | 0.10 mm / 4 mils |
| SKEW ANGLE | ± 50° |
| PITCH ANGLE | ± 65° |
| AIMING LASER | VLD, wavelength 630~680 nm |
| BAR CODES | UPC A, UPC E, EAN 8, EAN 13, Code 39, Code 39 Full ASCII, Code 32, Interleaved 2 of 5, Industrial 2 of 5, Matrix 2 of 5, Code 128, EAN 128, Codabar, MSI, Plessey, Code 93, Code 11, GS1 Databar |
| LASER CLASSIFICATION | Laser: Class 2 Safety class EN 60825-1:2001 |
| LED CLASSIFICATION | Led (Green Spot): Class 1 |
| IMAGER CHARACTERISTICS | |
| SCANNING RATE | 60 frames/sec |
| MAXIMUM RESOLUTION | 0.13 mm / 5 mils |
| AIMING LASER | VLD, wavelength 645~665 nm |
| BAR CODES | Decoded barcodes 1D: UPC A, UPC E, EAN 8, EAN 13, Interleaved 2 of 5, Code 39, Code 39 Full ASCII, Codabar, Code 128, EAN 128, Code 93, GS1 Databar, MSI, Bookland EAN, ISSN EAN; Matrix 2 of 5, Standard 2 of 5 |
| | Decoded barcodes 2D: PDF417, DataMatrix, QR, MicroPDF, RSS, Maxicode, Aztec |
| | Postal codes: POSTNET, PLANET, Japan Post, Australia Post, KIX Code, Royal Mail Code (RM4SCC), Intelligent mail, UPU FICS |
| LASER CLASSIFICATION | Laser: Class 2 Safety class: N 60825-1:2001 |
| LED CLASSIFICATION | Led (Illuminator): Class 1M |
| ILLUMINATION SYSTEM | LEDs 620~630 nm |

4.2 Reading Diagrams


DT10

Typical Reading Diagram - Reading Zones (10° skew angle)



SE4500-DL

Typical Reading Diagram - Reading Zones (10° skew angle)



Chapter 5 – Test Codes

High Density Codes

0.25 mm (10 mils)

Code 39



2/5 Interleaved



Code 128



EAN 13



EAN 8



Medium Density Codes

0.38 mm (15 mils)

Code 39



Interleaved 2/5



Code 128



EAN 13



EAN 8



Low Density Codes

0.50 mm (20 mils)

Code 39



Interleaved 2/5



Code 128



EAN 13



EAN 8



2D Codes

Datamatrix
ECC200



Example

Inverse
Datamatrix ECC200



Example

Safety Regulations

Read this manual carefully before performing any type of connection to the DT10 mobile computer.

The user is responsible for any damages caused by incorrect use of the equipment or by inobservance of the indication supplied in this manual.

General Safety Rules

- Use only the components supplied by the manufacturer for the specific DT10 being used.
- Do not attempt to disassemble the DT10 mobile computer, as it does not contain parts that can be repaired by the user. Any tampering will invalidate the warranty.
- When replacing the battery pack or at the end of the operative life of the DT10 mobile computer, disposal must be performed in compliance with the laws in force.
- Before using the devices and the battery packs, read Chapter 2.
- Do not submerge the DT10 in liquid products.
- For further information, refer to this manual and to the Wasp web site: www.waspbarcode.com.

Power Supply

This device is intended to be connected to a UL Listed/CSA Certified computer which supplies power directly to the DT10 or else be supplied by a UL Listed/CSA Certified Power Unit marked “Class 2” or LPS power source rated 5 V, 3.0 A, which supplies power directly to the DT10 via the power connector of the cable.

The package includes three international plug adapters. The adapters must be plugged in the power supply before the power supply itself is plugged on the wall outlet.

Laser Safety

The laser light is visible to the human eye and is emitted from the window indicated in the figure. This information applies to both laser models and the DT10 Imager Aiming System.

Laser output



ENGLISH

The following information is provided to comply with the rules imposed by international authorities and refers to the correct use of your mobile computer.

STANDARD LASER SAFETY REGULATIONS

This product conforms to the applicable requirements of both CDRH 21 CFR 1040 Subchapter J and EN 60825-1:2001 at the date of manufacture.

For installation, use and maintenance, it is not necessary to open the device.



CAUTION

Do not attempt to open or otherwise service any components in the optics cavity. Opening or servicing any part of the optics cavity by unauthorized personnel may violate laser safety regulations. The optics system is a factory only repair item.



CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in exposure to hazardous visible laser light.

The product utilizes a low-power laser diode. Although staring directly at the laser beam momentarily causes no known biological damage, avoid staring at the beam as one would with any very strong light source, such as the sun. Avoid that the laser beam hits the eye of an observer, even through reflective surfaces such as mirrors, etc.



CAUTION

Use of optical systems with the scanner will increase eye hazard. Optical instruments include binoculars, microscopes, eye glasses and magnifying glasses.

ITALIANO

Le seguenti informazioni vengono fornite dietro direttive delle autorità internazionali e si riferiscono all'uso corretto del terminale.

NORMATIVE STANDARD PER LA SICUREZZA LASER

Questo prodotto risulta conforme alle normative vigenti sulla sicurezza laser alla data di produzione: CDRH 21 CFR 1040 sezione J e EN 60825-1:2001.

Non si rende mai necessario aprire l'apparecchio per motivi di installazione, utilizzo o manutenzione.



ATTENZION

E

Non tentare di accedere allo scomparto contenete i componenti ottici o di farne la manutenzione.

L'apertura dello scomparto, o la manutenzione di qualsiasi parte ottica da parte di personale non autorizzato, potrebbe violare le norme della sicurezza. Il sistema ottico può essere riparato solamente alla fabbrica.



ATTENZION

E

L'utilizzo di procedure o regolazioni differenti da quelle descritte nella documentazione può provocare un'esposizione pericolosa a luce laser visibile.

Il prodotto utilizza un diodo laser a bassa potenza. Sebbene non siano noti danni riportati dall'occhio umano in seguito ad una esposizione di breve durata, evitare di fissare il raggio laser così come si eviterebbe qualsiasi altra sorgente di luminosità intensa, ad esempio il sole. Evitare inoltre di dirigere il raggio laser negli occhi di un osservatore, anche attraverso superfici riflettenti come gli specchi.



ATTENZION

E

L'uso di strumenti ottici assieme allo scanner può aumentare il pericolo di danno agli occhi. Tali strumenti ottici includono cannocchiali, microscopi, occhiali e lenti di ingrandimento.

DEUTSCH

Die folgenden Informationen stimmen mit den Sicherheitshinweisen überein, die von internationalen Behörden auferlegt wurden, und sie beziehen sich auf den korrekten Gebrauch vom Terminal.

NORM FÜR DIE LASERSICHERHEIT

Dies Produkt entspricht am Tag der Herstellung den gültigen EN 60825-1:2001 und CDRH 21 CFR 1040 Subchapter J Normen für die Lasersicherheit.

Es ist nicht notwendig, das Gerät wegen Betrieb oder Installations-, und Wartungs-Arbeiten zu öffnen.

**ACHTUNG**

Unter keinen Umständen darf versucht werden, die Komponenten im Optikhohlraum zu öffnen oder auf irgendwelche andere Weise zu warten. Das Öffnen bzw. Warten der Komponenten im Optikhohlraum durch unbefugtes Personal verstößt gegen die Laser-Sicherheitsbestimmungen. Das Optiksystem darf nur werkseitig repariert werden.

**ACHTUNG**

Jegliche Änderungen am Gerät sowie Vorgehensweisen, die nicht in dieser Betriebsanleitung beschrieben werden, können ein gefährliches Laserlicht verursachen.

Der Produkt benutzt eine Laserdiode. Obwohl zur Zeit keine Augenschäden von kurzen Einstrahlungen bekannt sind, sollten Sie es vermeiden für längere Zeit in den Laserstrahl zu schauen, genauso wenig wie in starke Lichtquellen (z.B. die Sonne). Vermeiden Sie es, den Laserstrahl weder gegen die Augen eines Beobachters, noch gegen reflektierende Oberflächen zu richten.

**ACHTUNG**

Die Verwendung von Optiksystemen mit diesem Scanner erhöht die Gefahr einer Augenbeschädigung. Zu optischen Instrumenten gehören unter anderem Ferngläser, Mikroskope, Brillen und Vergrößerungsgläser.

FRANÇAIS

Les informations suivantes sont fournies selon les règles fixées par les autorités internationales et se réfèrent à une correcte utilisation du terminal.

NORMES DE SECURITE LASER

Ce produit est conforme aux normes de sécurité laser en vigueur à sa date de fabrication: CDRH 21 CFR 1040 sous-chapitre J et EN 60825-1:2001.

Il n'est pas nécessaire d'ouvrir l'appareil pour l'installation, l'utilisation ou l'entretien.



Ne pas essayer d'ouvrir ou de réparer les composants de la cavité optique. L'ouverture de

ATTENTION *la cavité optique ou la réparation de ses composants par une personne non qualifiée peut entraîner le nonrespect des règles de sécurité relatives au laser. Le système optique ne peut être réparé qu'en usine.*



ATTENTION

L'utilisation de procédures ou réglages différents de ceux donnés ici peut entraîner une dangereuse exposition à lumière laser visible.

Le produit utilise une diode laser. Aucun dommage aux yeux humains n'a été constaté à la suite d'une exposition au rayon laser. Eviter de regarder fixement le rayon, comme toute autre source lumineuse intense telle que le soleil. Eviter aussi de diriger le rayon vers les yeux d'un observateur, même à travers des surfaces réfléchissantes (miroirs, par exemple).



ATTENTION

L'utilisation d'instruments optiques avec le scanneur augmente le danger pour les yeux. Les instruments optiques comprennent les jumelles, les microscopes, les lunettes et les verres grossissants.

ESPAÑOL

Las informaciones siguientes son presentadas en conformidad con las disposiciones de las autoridades internacionales y se refieren al uso correcto del terminal.

NORMATIVAS ESTÁNDAR PARA LA SEGURIDAD LÁSER

Este aparato resulta conforme a las normativas vigentes de seguridad láser a la fecha de producción: CDRH 21 CFR 1040 Sección J y EN 60825-1:2001.

No es necesario abrir el aparato para la instalación, la utilización o la manutención.

**ATENCIÓN**

No intente abrir o de ninguna manera dar servicio a ninguno de los componentes del receptáculo óptico.

Abrir o dar servicio a las piezas del receptáculo óptico por parte del personal no autorizado podría ser una violación a los reglamentos de seguridad. El sistema óptico se puede reparar en la fábrica solamente.

**ATENCIÓN**

La utilización de procedimientos o regulaciones diferentes de aquellas descritas en la documentación puede causar una exposición peligrosa a la luz láser visible.

El aparato utiliza un diodo láser a baja potencia. No son notorios daños a los ojos humanos a consecuencia de una exposición de corta duración. Eviten de mirar fijo el rayo láser así como evitarían cualquiera otra fuente de luminosidad intensa, por ejemplo el sol. Además, eviten de dirigir el rayo láser hacia los ojos de un observador, también a través de superficies reflectantes como los espejos.

**ATENCIÓN**

El uso de sistemas ópticos con el escáner aumentará el riesgo de daños oculares. Los instrumentos ópticos incluyen binoculares, microscopios, lentes y lupas.

LED Class

According to EN60825-1:2001, the DT10 1D models which use the green spot LED are also CLASS 1 LED PRODUCTS.

APPARECCHIO LED CLASSE 1 IEC

PRODUIT LED DE CLASSE 1 IEC

PRODUKT LED KLASSE 1 IEC

PRODUCTO LED DE CLASE 1 IEC

According to EN60825-1:2001, the DT10 2D models which use the illuminator LED are also CLASS 1M LED PRODUCTS.

LED LIGHT

LUCE LED

DO NOT VIEW DIRECTLY

NON OSSERVARE

WITH OPTICAL INSTRUMENTS

DIRETTAMENTE

CLASS 1M LED PRODUCT

CON STRUMENTI OTTICI

APPARECCHIO LED DI CLASSE

1M

LAMPE LED

LUZ LED

NE PAS OBSERVER

NO OBSERVAR DIRECTAMENTE

DIRECTEMENT

CON INSTRUMENTOS

AVEC INSTRUMENTS

ÓPTICOS.

OPTIQUES

PRODUCTO LED DE CLASE 1M

APPAREIL LED DE CLASSE 1M

LED-LICHT

NICHT DIREKT MIT OPTISCHEN

INSTRUMENTEN BETRACHTEN.

GERÄTEKLASSE 1M.

Radio Compliance

In radio systems configured with mobile computers and access points, the frequencies to be used must be allowed by the spectrum authorities of the specific country in which the installation takes place. Be absolutely sure that the system frequencies are correctly set to be compliant with the spectrum requirements of the country.

The Radio modules used in this product automatically adapt to the frequencies set by the system and do not require any parameter settings.

The following shows the correspondence between the DT10 models and the Radio components:

- DL-DT10+802.11+BT models: 802.11a/b/g and BT radio modules

CE0700!

Information for the User

ENGLISH

Contact the competent authority responsible for the management of radio frequency devices of your country to verify any possible restrictions or licenses required.

Refer to the web site <http://europa.eu.int/comm/enterprise/rte/spectr.htm> for further information.

ITALIANO

Prendi contatto con l'autorità competente per la gestione degli apparati a radio frequenza del tuo paese, per verificare eventuali restrizioni o licenze. Ulteriori informazioni sono disponibili sul sito:

<http://europa.eu.int/comm/enterprise/rte/spectr.htm>.

FRANÇAIS

Contactez l'autorité compétente en la gestion des appareils à radio fréquence de votre pays pour vérifier d'éventuelles restrictions ou licences. Pour tout renseignement vous pouvez vous adresser au site web:

<http://europa.eu.int/comm/enterprise/rte/spectr.htm>.

DEUTSCH

Wenden Sie sich an die für Radiofrequenzgeräte zuständige Behörde Ihres Landes, um zu prüfen ob es Einschränkungen gibt, oder eine Lizenz erforderlich ist. Weitere Informationen finden Sie auf der Web Seite:

<http://europa.eu.int/comm/enterprise/rte/spectr.htm>.

ESPAÑOL

Contacta la autoridad competente para la gestión de los dispositivos de radio frecuencia de tu país, para verificar cualesquiera restricciones o licencias posibles requerida. Además se puede encontrar mas información en el sitio

Web: <http://europa.eu.int/comm/enterprise/rte/spectr.htm>.

FCC Compliance

FCC Regulations:

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- This device is restricted to indoor use when operated in the 5.15 to 5.25 GHz frequency range.

RF Exposure Information (SAR)

This model device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model device as reported to the FCC are the following:

- DT10 + 802.11 + BT models: for use at the head is 1.32 W/Kg and when worn on the body, as described in the user guide, is 0.518 W/Kg. (Body-worn measurements differ among device models, depending upon available enhancements and FCC requirements).

While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on the below FCC ID: FCC ID: U4GA030 for DL-DT10+802.11+BT models.

This device is compliant with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.5 cm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the device at the ear, position the handset a minimum of 1.5 cm from your body when the device is switched on.

Industry Canada Compliance

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

The County Code Selection feature is disabled for products marketed in the US/Canada.

IMPORTANT NOTE:

IC Radiation Exposure Statement

This EUT is compliant with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528. This equipment should be installed and operated with minimum distance 1,5cm between the radiator & your body.

Be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

SAR Compliance

This product has been tested and found to comply with the following standards:

- OET BULLETIN 65 SUPPLEMENT C: evaluating compliance with FCC guidelines for human exposure to radio frequency electromagnetic fields.
- EN 62311:2008: assessment of electronic and electrical equipment related to human exposure restrictions for electromagnetic fields (0 Hz – 300 GHz).

Patents

This product is covered by one or more of the following patents.

Design Pat. Nos: EP 469,143; EP 1,582,024; AU 310182 S; CN 658612; HK 0601962.6; KR 30-0466667; JP1325117; TW D118829; US D574,830 S.

US Pat. Nos: 5,992,740; 6,808,114 B1; 6,997,385 B2; 7,387,246 B2.

European Pat. Nos: 681,257 B1; 789,315 B1; 1,128,315 B1; 1,396,811 B1; 1,413,971 B1.

Additional patents pending.

WEEE Compliance



Informazione degli utenti ai sensi della Direttiva Europea 2002/96/EC

L'apparecchiatura che riporta il simbolo del bidone barrato deve essere smaltita, alla fine della sua vita utile, separatamente dai rifiuti urbani.

Smaltire l'apparecchiatura in conformità alla presente Direttiva consente di:

- evitare possibili conseguenze negative per l'ambiente e per la salute umana che potrebbero invece essere causati dall'errato smaltimento dello stesso;
- recuperare materiali di cui è composto al fine di ottenere un importante risparmio di energia e di risorse.

Per maggiori dettagli sulle modalità di smaltimento, contattare il Fornitore dal quale è stata acquistata l'apparecchiatura o consultare la sezione dedicata sul sito www.waspbarcode.com.

Information for the user in accordance with the European Commission Directive 2002/96/EC

At the end of its useful life, the product marked with the crossed out wheeled wastebin must be disposed of separately from urban waste.

Disposing of the product according to this Directive:

- avoids potentially negative consequences to the environment and human health which otherwise could be caused by incorrect disposal
- enables the recovery of materials to obtain a significant savings of energy and resources.

For more detailed information about disposal, contact the supplier that provided you with the product in question or consult the dedicated section at the website www.waspbarcode.com.

Information aux utilisateurs concernant la Directive Européenne 2002/96/EC

Au terme de sa vie utile, le produit qui porte le symbole d'un caisson à ordures barré ne doit pas être éliminé avec les déchets urbains.

Éliminer ce produit selon cette Directive permet de:

- éviter les retombées négatives pour l'environnement et la santé dérivant d'une élimination incorrecte
- récupérer les matériaux dans le but d'une économie importante en termes d'énergie et de ressources

Pour obtenir des informations complémentaires concernant l'élimination, veuillez contacter le fournisseur auprès duquel vous avez acheté le produit ou consulter la section consacrée au site Web www.waspbarcode.com.

Información para el usuario de acuerdo con la Directiva Europea 2002/96/CE

Al final de su vida útil, el producto marcado con un simbolo de contenedor de bassura móvil tachado no debe eliminarse junto a los desechos urbanos.

Eliminar este producto de acuerdo con la Directiva permite de:

- evitar posibles consecuencias negativas para el medio ambiente y la salud derivadas de una eliminación inadecuada
- recuperar los materiales obteniendo así un ahorro importante de energía y recursos

Para obtener una información más detallada sobre la eliminación, por favor, póngase en contacto con el proveedor donde lo compró o consultar la sección dedicada en el Web site www.waspbarcode.com.

Benutzerinformation bezüglich Richtlinie 2002/96/EC der europäischen Kommission

Am Ende des Gerätelebenszyklus darf das Produkt nicht über den städtischen Hausmüll entsorgt werden. Eine entsprechende Mülltrennung ist erforderlich.

Beseitigung des Produkts entsprechend der Richtlinie:

- verhindert negative Auswirkungen für die Umwelt und die Gesundheit der Menschen
- ermöglicht die Wiederverwendung der Materialien und spart somit Energie und Ressourcen

Weitere Informationen zu dieser Richtlinie erhalten sie von ihrem Lieferanten über den sie das Produkt erworben haben, oder besuchen sie unsere Homepage unter www.waspbarcode.com.

China RoHS Pollution Control Logos

| Part name | Toxic or Hazardous Substances and Elements for DL-DT10 | | | | | |
|---|--|----|----|------|-----|------|
| | Pb | Hg | Cd | Cr6+ | PBB | PBDE |
| Upper Case | O | O | O | O | O | O |
| Lower Case | O | O | O | O | O | O |
| Touch Panel | O | O | O | O | O | O |
| PCB Board | O | O | O | O | O | O |
| Laser Engine | X | O | O | O | O | O |
| Imager Engine | O | O | O | O | O | O |
| BT Module (Note 1) | O | O | O | O | O | O |
| 802.11 a/b/g Radio Module (Note 1) | O | O | O | O | O | O |
| <p>99% of the parts of this product adopt the nonpoisonous and harmless environmental protection material to make, the part with poisonous harmful substance or the element is all unable to realize the substitution of the poisonous harmful thing or the element because the global technological development level is limited.</p> <p>O: Indicates that this is a toxic or hazardous substance contained in all of the homogenous materials for this part is below the limit requirement in SJ/T11363-2006.</p> <p>X: Indicates that this is toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.</p> <p>Note 1: It is only for 944201038, 944201039, 944201040, 944201041.</p> | | | | | | |

Glossary

Access Point

A device that provides transparent access between Ethernet wired networks and IEEE 802.11 interoperable radio-equipped mobile units. Hand-held mobile computers, PDAs or other devices equipped with radio cards, communicate with wired networks using Access Points (AP). The mobile unit (mobile computer) may roam among the APs in the same subnet while maintaining a continuous, seamless connection to the wired network.

Applet

Diminutive form of app (application), it refers to simple, single-function programs that often ship with a larger product. Programs such as Windows' Calculator, File Manager, and Notepad are examples of applets.

Barcode

A pattern of variable-width bars and spaces which represents numeric or alphanumeric data in binary form. The general format of a barcode symbol consists of a leading margin, start character, data or message character, check character (if any), stop character, and trailing margin. Within this framework, each recognizable symbology uses its own unique format.

Baud Rate

A measure for data transmission speed.

Bit

Binary digit. One bit is the basic unit of binary information. Generally, eight consecutive bits compose one byte of data. The pattern of 0 and 1 values within the byte determines its meaning.

Bluetooth®

A standard radio technology using a proprietary protocol. The onboard Bluetooth® module in the mobile computer is compatible with the 1.1 protocol.

Byte

On an addressable boundary, eight adjacent binary digits (0 and 1) combined in a pattern to represent a specific character or numeric value. Bits are numbered from the right, 0 through 7, with bit 0 the low-order bit. One byte in memory can be used to store one ASCII character.

Decode

To recognize a bar code symbology (e.g., Codabar, Code 128, Code 3 of 9, UPC/EAN, etc.) and analyze the content of the bar code scanned.

Depth of Field (DOF)

The portion of a scene that appears acceptably sharp in the image. Although a lens can precisely focus at only one distance, the decrease in sharpness is gradual on each side of the focused distance, so that within the DOF, the unsharpness is imperceptible under normal viewing conditions.

EEPROM

Electrically Erasable Programmable Read-Only Memory. An on-board non-volatile memory chip.

Ethernet

The standard local area network (LAN) access method. A reference to "LAN," "LAN connection" or "network card" automatically implies Ethernet. Defined by the IEEE as the 802.3 standard, Ethernet is used to connect computers in a company or home network as well as to connect a single computer to a cable modem or DSL modem for Internet access.

Firmware

Firmware is a software program or set of instructions programmed on a hardware device. It provides the necessary instructions for how the device communicates with the other computer hardware. Firmware is typically stored in the flash ROM of a hardware device. While ROM is "read-only memory," flash ROM can be erased and rewritten because it is actually a type of flash memory.

Flash Disk

Non-volatile memory for storing application and configuration files.

Host

A computer that serves other mobile computers in a network, providing services such as network control, database access, special programs, supervisory programs, or programming languages.

IEEE 802.11

A set of standards carrying out wireless local area network (WLAN) computer communication in the 2.4, 3.6 and 5 GHz frequency bands. They are created and maintained by the IEEE LAN/MAN Standards Committee.

Liquid Crystal Display (LCD)

A display that uses liquid crystal sealed between two glass plates. The crystals are excited by precise electrical charges, causing them to reflect light outside according to their bias. They use little electricity and react relatively quickly. They require external light to reflect their information to the user.

Light Emitting Diode (LED)

A low power electronic light source commonly used as an indicator light. It uses less power than an incandescent light bulb but more than a Liquid Crystal Display (LCD).

Null modem cable

RS-232 serial cable where the transmit and receive lines are crosslinked. In some cables there are also handshake lines crosslinked. In many situations a straight through serial cable is used, together with a null modem adapter. The adapter contains the necessary crosslinks between the signals.

Pairing

A Bluetooth pairing occurs when two Bluetooth devices agree to communicate with each other and establish a connection.

Piconet

A piconet is a Bluetooth PAN that links up to eight devices. Each piconet is controlled by one master device, and up to seven slave devices at any one time. Any device may be a member of more than one piconet, changing its membership as a user moves from one area to another.

RAM

Random Access Memory. Data in RAM can be accessed in random order, and quickly written and read.

RF

Radio Frequency.

RTC

Real Time Clock.

TDMA

Time division multiple access (TDMA) is digital transmission technology that allows a number of users to access a single radio-frequency (RF) channel without interference by allocating unique time slots to each user within each channel. The TDMA digital transmission scheme multiplexes three signals over a single channel. The current TDMA standard for cellular divides a single channel into six time slots, with each signal using two slots, providing a 3 to 1 gain in capacity over advanced mobile-phone service (AMPS). Each caller is assigned a specific time slot for transmission.

USB

Universal Serial Bus. Type of serial bus that allows peripheral devices (disks, modems, printers, digitizers, data gloves, etc.) to be easily connected to a computer. A “plug-and-play” interface, it allows a device to be added without an adapter card and without rebooting the computer (the latter is known as hot-plugging). The USB standard, developed by several major computer and telecommunications companies, supports data-transfer speeds up to 12 megabits per second, multiple data streams, and up to 127 peripherals.

WLAN

A Wireless Local Area Network links devices via a wireless distribution method (typically spread-spectrum or OFDM radio), and usually provides a connection through an access point to the wider internet. This gives users the mobility to move around within a local coverage area and still be connected to the network.

WPAN

A Wireless Personal Area Network is a personal area network - a network for interconnecting devices centered around an individual person's workspace - in which the connections are wireless. Typically, a wireless personal area network uses some technology that permits communication within about 10 meters - in other words, a very short range.