Manual Addendum for WWS100i and WWS550i:

Barcodes scanned into Word or Excel which include embedded Tab, Enter, or Escape characters will not send those characters in a way that is properly interpretted by the Office application. Use these two barcodes to enable or disable an output mode that Office will understand.

Enable HT/CR/ESC output as Tab/Enter/Escape



.D025$

Disable HT/CR/ESC output as Tab/Enter/Escape



.D026$